
Drive 

User's manual

MODEL : EEDV06

Thank you for using Drive cars AV system series of products. To get the best performance, please read the manual carefully and keep it well for reference.

Safety Considerations

Warning

In order to prevent injuries and fires and other accidents, please observe the following precautions:

☆ Prohibit the driver to operate the equipment in driving.

If operate it in driving, can make driver pay less attention and easily lead to accidents, so please stop the car to use it.

- Do not put metal (coin, tool etc.) into the equipment, to avoid short circuit fault.
- Do not drop the equipment or hit by a violent collision.
- During operation if smokes, smells or no sound etc. May cause electrical fire, turn off the power immediately, and consult the dealer you purchased from

Caution!

☆ In order to prevent machine failure, please observe the following precautions and operate correctly:

- Please find professional and technical personnel for your installation and wiring.
- Installation and wiring of the machine requires specialized technology and experience; for security reasons, ask your dealer to manage it.

- Do not disassemble and transform the machine, which may cause smoke, electrical fire and other failure.
- Do not put metal or unusual object into the machine, which may destroy the machine.
- Please be sure to use the specified fuse, if use irregularities fuse, may lead to smoke, electrical fire and other failure.
- During installation, be sure to use the machine attachment, otherwise, may cause the unit to malfunction.

Content

How to play the disc	3
Terms about the disc.....	3
Disc notes.....	4
About this manual.....	4
Accessory Check.....	5
The use of the remote control.....	5
Name and function introduction.....	6
System connection.....	7
Basic operations.....	8
Failure countermeasures.....	8
Technical Specifications.....	9

How to play the disc

Face up the disc label side, the fingers do not touch the signal track area, gently push it into the entrance, after the machine detects the disc would automatically swallow the disc, in this process, do not strongly push the disc.

This unit can not play three inches (8MM) disc, if put into the 8MM disc into this unit, playback may damage the machine.



Terms about the disc

1. Title

DVD image or music is divided into several parts, the largest unit is: title. For a section image of the video software, the largest unit is video. For a piece of music in the audio software, the largest unit is music. Each title has a title number, makes it easy to be found.

2. Chapter

DVD in units of image or music part smaller than title, Usually a title composed by chapters, each chapter has a chapter number in order to be found, some discs may not have record of chapters.

3. Track

In VCD or CD image or music part, each track has a track number in order to be found.

4. Scene

Menu screen, animation and static painting of Super CD, VCD with PBC function is divided into "scenes" section.

PBC playback control (Super CD, VCD recorded in Super CD, VCD) version signal on the disc.

Disc type	Function
Without PBC function VCD(1.1 version)	Can play music, but also can play the image (animation)
Super VCD, CD disc with PBC function	In addition to VCD1.1 Edition the disc image playback function, can also play interactive software using menu screen displayed on the TV screen (PBC Playback)

Disc notes


Using the disc:

1. To keep the disc clean, take the the disc edges, do not touch the surface.
2. Do not paste paper or tape on the disc.
3. Do not allow the the disc in direct sunlight or near heat sources.
4. After playing, put the disc in the storage box.

On cleaning

2. Clean the disc with a clean cloth before playback, wipe the disc from the center outward.
1. Do not use volatile petrol or thinners. Commercially available cleaners or plastic disc, use anti-static spray solution.

About this manual

1. This manual describe About the operati on of the buttons on the remote control and buttons on this machine.
2.  Appears on the display screen indicates the current operation is prohibited by the disc or improper operation.
3. This unit can play the following discs

Disc type	Recorded content	Disc size
DVD	Audio+Video (dynamic picture)	12MM
VCD	Audio+Video (dynamic picture)	12MM
CD	Audio	12MM
Mp3	Audio	12MM
Kodak picture CD	Video	12MM
HDCD	Audio	12MM


This machine is compatible with CD / VCD / DVD / HDCD television video signal format

Accessory Check

After unpacking, please check if the following parts are complete.

1. Power cable 1PC
2. AV cable 1PC
3. Remote control 1PC
4. User's manual 1PCS

Use of the remote controller



1	Power	14	Number Keys
2	Play/Pause	15	Audio Setting
3	Mute	16	PBC Menu
4	Selecting Menu	17	Subtitle Setting
5	Band/System	18	Playing Time Setting
6	Enter	19	Mode Switch
7	Volume Control	20	Stop Playback
8	Tuning/Selecting/FW/RW	21	Angle Setting
9	Program Playback	22	Slow Motion Playback
10	On-Screen Display	23	Setup Menu
11	Setting the Sound	24	Menu Display
12	Repeat Playback	25	Zoom Setting
13	Random Playback		


Warning:

1. Do not put the remote control at a hot place, like dashboard.
2. Be sure the unused battery is placed where children can not reach.
3. Use the remote control directly facing the receiver window, there should not be any obstacles between remote control and receiver window.
4. If the remote control is not working well, replace two new batteries.
5. When unused for long periods of time, remove the batteries to prevent battery liquid leakage and damage the body.

Name and function introduction




1.POWER	12.BLUETOOTH SWITCH
2.PLAY/PAUSE	13.MUTE GROUP A SPEAKER
3.SUB SWITCH	14.MUTE GROUP B SPEAKER
4.MODE	15.MUTE GROUP C SPEAKER
5.REMOTE CONTROL RECEIVER	16.DISC OUT
6.MIC	17.SYSTEM REST
7.SD INPUT	18.AUX INPUT
8.BAND	19.USB INPUT
9.TUNING/SELECTING RW	20.VOL
10.TUNING/SELECTING FW	21.LCD SCREEN
11.CLOCK	22.ENTRANCE AND EXIT OF DISC
23.Blustooth NFC.Cell phone close to the NFC area.will be autom atically connected	




NOTE:Open the phone bluetooth, find the ID: Carkit and connection, in the condition.
 NOTE:DVD will switch to bluetooth mode.will open, cell phone bluetooth and NFC mobile phone NFC area near the DVD NFC area, when the mobile phone in "drops" after the prompt, marking the connection is successful, disconnected, again approached, they can appeqr"drops"prompt.

System connection



Signal output interface definition



WIRING COLOR CODE

PIN COLOR	FUNCTION
1. PINK/BLACK	RIGHT(C) SPEAKER(-)
2. PINK	RIGHT(C) SPEAKER(+)
3. DARK GREEN	LEFT(C) SPEAKER(+)
4. DARK GREEN/BLACK	LEFT(C) SPEAKER(-)
5. BROWN/BLACK	LEFT(B) SPEAKER(-)
6. GRAY	FRONT RIGHT(A) SPEAKER(+)
7. GRAY/BLACK	FRONT RIGHT(A) SPEAKER(-)
8. RED	+ 12VDC SWITCHED
9. WHITE/BLACK	FRONT LEFT(A) SPEAKER(-)
10. WHITE	FRONT LEFT(A) SPEAKER(+)
11. ORANGE	RIGHT(B) SPEAKER(+)
12. ORANGE/BLACK	RIGHT(B) SPEAKER(-)
13. BROWN	LEFT(B) SPEAKER(+)
14. BLUE	AMP REMOTE(+12VDC 100MA)
15. YELLOW	MEMORY/BATTERY(+)
16. BLACK	GROUND
17. VIOLET	A ROOM SUBWOOFER(+)
18. VIOLET/BLACK	A ROOM SUBWOOFER(-)

Technical Specifications

DVD part technical specifications

Laser wavelength	650nm
Video system	PAL/NTSC/AUTO
Audio response	20HZ~20000HZ
Audio signal noise ratio	$\geq 90\text{dB}(1\text{KHZ})$
Audio distortion + noise	$\leq -70\text{dB} (1\text{KHZ})$
Channel Isolation	$\geq 70\text{dB}(1\text{KHZ})$
Audio output	Output level: 2v, Load impedance: 10k Ω
Video output	Output level: 1vp-p, Load impedance: 75 Ω
Power supply	12V/DC
Speaker Power	10W/*6PCS
Size	240MM*206MM*160MM

Remarks: Our company continues to improve product performance, if any change of design and specification, to prevail in kind, there would be no other notice.